

荷梓坞小百科一:千板尺表(Doyle检尺)

原木长度(单位:英尺)

原木直径(单位:英寸)
原木小头皮下平均直径

	6'	7'	8'	9'	10'	11'	12'	13'	14'	15'	16'	17'
10"	13	16	18	20	23	25	27	29	32	34	36	38
11"	18	21	24	28	31	34	37	40	43	46	49	52
12"	24	28	32	36	40	44	48	52	56	60	64	68
13"	30	35	40	45	50	55	61	66	71	76	81	86
14"	38	44	50	56	62	69	75	81	88	94	100	106
15"	45	53	60	68	75	83	91	98	106	113	121	128
16"	54	63	72	81	90	99	108	117	126	135	144	153
17"	63	74	84	95	106	116	127	137	148	158	169	180
18"	73	85	98	110	122	135	147	159	171	184	196	208
19"	84	98	112	127	141	155	169	183	197	211	225	239
20"	96	112	128	144	160	176	192	208	224	240	256	272
21"	108	126	144	162	181	199	217	235	253	271	289	307
22"	121	142	162	182	202	223	243	263	283	303	324	344
23"	135	156	180	203	226	248	271	293	313	337	359	383
24"	150	175	200	225	250	275	300	325	350	375	400	425
25"	165	193	220	248	276	303	331	358	386	413	441	469
26"	181	212	242	272	302	332	363	393	423	454	484	514
27"	198	231	264	297	330	364	397	430	463	496	530	563
28"	216	252	288	324	360	396	432	468	504	540	576	612
29"	235	273	312	352	391	430	469	508	547	586	625	664
30"	253	295	338	380	422	464	507	549	591	634	676	718
31"	273	319	364	410	456	502	547	592	638	683	729	774
32"	294	343	392	441	490	539	588	637	686	735	784	833
33"	315	368	420	473	526	578	631	684	736	789	841	894
34"	337	394	450	506	562	619	675	731	787	844	900	956
35"	360	420	480	540	601	661	721	781	841	901	961	1021
36"	384	448	512	576	640	704	768	832	896	960	1024	1088
37"	408	476	544	613	681	749	817	885	953	1021	1089	1157
38"	433	505	578	650	723	795	867	939	1011	1083	1156	1228
39"	459	536	612	689	765	841	919	995	1072	1149	1225	1302
40"	486	566	648	729	810	891	972	1053	1134	1215	1296	1377
41"	513	599	684	770	856	941	1027	1112	1198	1284	1369	1454
42"	541	632	722	812	902	993	1083	1173	1264	1354	1444	1534
43"	570	665	761	856	951	1046	1141	1236	1331	1426	1521	1617
44"	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700

